

Step-by-Step Instructions for Motor Reset on SkyGuider Pro

October 2017

Tools needed: 2 mm and 2.5 mm hex key (Allen wrench).

Step 1- Remove the two screws at the front of the mount (2 mm hex key).



Step 2- Remove the screws on the top (2.5 mm hex key).



Step 3- Remove the black cover. Turn the encoder (wheel) 180 degrees.



Step 4- Turn the power switch on while pressing the middle button. The motor should spin in fast speed for 10 min, (if the motor does not run, repeat step 3). When motor stopped, press the middle button again, the motor should reverse spin for 10 min. Repeat one more time spin each direction. Put the cover back.

